

## Warranty, Service & Repair

To register your product with the manufacturer, go to the Flowline website for on-line registration. The website address is as follows:

**www.flowline.com**

On-line Warranty Registration can be found under Contact Us in the Navigation Bar along the side of the home page.

If for some reason your product must be returned for factory service, contact Flowline Inc. at (562)598-3015 to receive a Material Return Authorization number (MRA), providing the following information:

1. Part Number, Serial Number
2. Name and telephone number of someone who can answer technical questions related to the product and its application.
3. Return Shipping Address
4. Brief Description of the Symptom
5. Brief Description of the Application

Once you have received a Material Return Authorization number, ship the product prepaid in its original packing to:

Flowline Factory Service  
MRA \_\_\_\_\_  
10500 Humbolt Street  
Los Alamitos, CA 90720

To avoid delays in processing your repair, write the MRA on the shipping label. Please include the information about the malfunction with your product. This information enables our service technicians to process your repair order as quickly as possible.

## **FLOWLINE®** **Switch Pro™** **w/ Compact Relay Controller** **A\_1\_ Series Owner's Manual**



Version 0.1A

© 2005 FLOWLINE Inc.

All rights reserved.

Manual # FT900005

05/05

## WARRANTY

Flowline warrants to the original purchaser of its products that such products will be free from defects in material and workmanship under normal use and service for a period which is equal to the shorter of one year from the date of purchase of such products or two years from the date of manufacture of such products.

This warranty covers only those components of the products which are non-moving and not subject to normal wear. Moreover, products which are modified or altered, and electrical cables which are cut to length during installation are not covered by this warranty.

Flowline's obligation under this warranty is solely and exclusively limited to the repair or replacement, at Flowline's option, of the products (or components thereof) which Flowline's examination proves to its satisfaction to be defective. FLOWLINE SHALL HAVE NO OBLIGATION FOR CONSEQUENTIAL DAMAGES TO PERSONAL OR REAL PROPERTY, OR FOR INJURY TO ANY PERSON.

This warranty does not apply to products which have been subject to electrical or chemical damage due to improper use, accident, negligence, abuse or misuse. Abuse shall be assumed when indicated by electrical damage to relays, reed switches or other components. The warranty does not apply to products which are damaged during shipment back to Flowline's factory or designated service center or are returned without the original casing on the products. Moreover, this warranty becomes immediately null and void if anyone other than service personnel authorized by Flowline attempts to repair the defective products.

Products which are thought to be defective must be shipped prepaid and insured to Flowline's factory or a designated service center (the identity and address of which will be provided upon request) within 30 days of the discovery of the defect. Such defective products must be accompanied by proof of the date of purchase.

Flowline further reserves the right to unilaterally waive this warranty and to dispose of any product returned to Flowline where:

- a. There is evidence of a potentially hazardous material present with product.
- b. The product has remained unclaimed at Flowline for longer than 30 days after dutifully requesting disposition of the product.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE OF THIS WARRANTY. This warranty and the obligations and liabilities of Flowline under it are exclusive and instead of, and the original purchaser hereby waives, all other remedies, warranties, guarantees or liabilities, express or implied. EXCLUDED FROM THIS WARRANTY IS THE IMPLIED WARRANTY OF FITNESS OF THE PRODUCTS FOR A PARTICULAR PURPOSE OR USE AND THE IMPLIED WARRANTY OF MERCHANT ABILITY OF THE PRODUCTS.

This warranty may not be extended, altered or varied except by a written instrument signed by a duly-authorized officer of Flowline, Inc.

# SPECIFICATIONS

## Step One

### Specifications:

Set point range:	AT1_: .04 to 3 fps (.012 to .91 mps) AG1_: 1 to 90 fps (.3 to 27 mps)
Factory set point:	AT1_: .2 fps (.06 mps) AG1_: 10 fps (3 mps)
Repeatability:	±.5% of set point @ fixed temp.
Response time:	1 to 10 seconds
Set point adjust.:	Potentiometer
Viscosity range:	AT1_: 1 to 200 centipoise AG1_: N/A
Supply voltage:	120/240 VAC @ 50-60 Hz.
Contact rating:	250 VAC @ 10A
Contact delay:	0 - 60 seconds
LED indication:	Power, relay and sensor status
Strobe type:	_61_: Xenon tube _62_: N/A
Strobe flash:	_61_: 1 per second _62_: N/A
Process temp.:	F: -40° to 194° C: -40° to 90°
Electronics temp.:	F: -40° to 140° C: -40° to 60°
Pressure:	150 psi (10 bar) @ 25 °C., derated @ 1.667 psi (.113 bar) per °C. above 25 °C.
Wetted material:	16_: PP-Ryton® 36_: PVDF Kynar®
Process mount:	3/4" NPT (3/4" G)
Mount. gasket:	Viton (G version only)
Enclosure rating:	NEMA 4X (IP65)
Encl. material:	_61_: PP, UL94VO and polycarbonate _62_: PP, UL94VO
Conduit entrance:	Single, 1/2" NPT
Classification:	General purpose
CE compliance:	EN 50082-2 immunity EN 55011 emission EN 61010-1 safety

### Sensor Technologies:

#### Thermal Dispersion - Liquid (FT10 series)




Best applied in clean water or water-like chemical media that is non-coating or crystallizing

#### Thermal Dispersion - Gas (GT10 series)




Best applied in clean air or aggressive media that is non-coating and particular free


### Dimensions (w/ long sensor):



### Dimensions (w/ short sensor):



### Dimensions (w/ short sensor and Strobe Alert):




## COMPONENTS

### Step Two


#### Standard Configuration:

AT14-\_\_6\_\_ and AG14-\_\_6\_\_




<u>AT14-1610</u>	<u>AG14-1610</u>	<u>AT14-1620</u>	<u>AG14-1620</u>
1 x FT10-1405	1 x GT10-1405	1 x FT10-1405	1 x GT10-1405
1 x LC10-1002	1 x LC10-1002	1 x LC10-1001	1 x LC10-1001
<u>AT14-1614</u>	<u>AG14-1614</u>	<u>AT14-1624</u>	<u>AG14-1624</u>
1 x FT10-1425	1 x GT10-1425	1 x FT10-1425	1 x GT10-1425
1 x LC10-1052	1 x LC10-1052	1 x LC10-1051	1 x LC10-1051
<u>AT14-3610</u>	<u>AG14-3610</u>	<u>AT14-3620</u>	<u>AG14-3620</u>
1 x FT10-5405	1 x GT10-5405	1 x FT10-5405	1 x GT10-5405
1 x LC10-1002	1 x LC10-1002	1 x LC10-1001	1 x LC10-1001
<u>AT14-3614</u>	<u>AG14-3614</u>	<u>AT14-3624</u>	<u>AG14-3624</u>
1 x FT10-5425	1 x GT10-5425	1 x FT10-5425	1 x GT10-5425
1 x LC10-1052	1 x LC10-1052	1 x LC10-1051	1 x LC10-1051

AT12-\_\_6\_\_ and AG12-\_\_6\_\_



<u>AT12-1610</u>	<u>AG12-1610</u>	<u>AT12-1620</u>	<u>AG12-1620</u>
1 x FT10-1305	1 x GT10-1305	1 x FT10-1305	1 x GT10-1305
1 x LC10-1002	1 x LC10-1002	1 x LC10-1001	1 x LC10-1001
<u>AT12-1614</u>	<u>AG12-1614</u>	<u>AT12-1624</u>	<u>AG12-1624</u>
1 x FT10-1325	1 x GT10-1325	1 x FT10-1325	1 x GT10-1325
1 x LC10-1052	1 x LC10-1052	1 x LC10-1051	1 x LC10-1051
<u>AT12-3610</u>	<u>AG12-3610</u>	<u>AT12-3620</u>	<u>AG12-3620</u>
1 x FT10-5305	1 x GT10-5305	1 x FT10-5305	1 x GT10-5305
1 x LC10-1002	1 x LC10-1002	1 x LC10-1001	1 x LC10-1001
<u>AT12-3614</u>	<u>AG12-3614</u>	<u>AT12-3624</u>	<u>AG12-3624</u>
1 x FT10-5325	1 x GT10-5325	1 x FT10-5325	1 x GT10-5325
1 x LC10-1052	1 x LC10-1052	1 x LC10-1051	1 x LC10-1051

#### Component List:



**Compact Relay Controller**  
P/N: LC10-1001, LC10-1051,  
LC10-1002 or LC10-1052



**Switch-Tek Level Switch**  
P/N: FT10-1305, FT10-1325,  
FT10-5305, FT10-5325,  
FT10-1405, FT10-1425,  
FT10-5405, FT10-5425

## CALIBRATION

### Step Three



**Set Points:** If the preset factory calibration is not adequate for your application, follow the calibration steps listed below. *Note: the switch's internal LED will be on when the switch detects no-flow and will off when the switch detects flow.*

1. Install the fitting and flow switch as described in the Installation section of this manual. Turn the flow switch and controller power on and adjust the flow rate to the application setting. If the medium to be sensed is likely to be subject to high temperature variations, the flow switch should be set at the highest normal temperature likely to be encountered.
2. Locate the potentiometer knob at the top of the flow switch. The red LED is visible through the potentiometer. (If the LED is on, slowly adjust the potentiometer counterclockwise, with a small flat head screwdriver until the LED turns off.) The adjustment is a single turn 270° potentiometer. The initial response time of the flow switch after adjustment is 1 to 10 seconds. Adjust the potentiometer in slow increments and wait for the response.  
  
If the LED is off, slowly adjust the potentiometer clockwise until the light turns on. Then turn the potentiometer counterclockwise to bring the LED off at a reliable setting. Remember, adjust the potentiometer in slow increments and wait for the response.
3. Verify that the new calibration is correct by lowering the system flow rate below the set point and check to see that the red LED turns on. Then increase the flow rate above the set point and verify that the red LED turns off accordingly.




**Liquid Switch**  
**AT1-\_\_63\_\_ Series**

**Gas Switch**  
**AG1-\_\_63\_\_ Series**



**Adjustment Potentiometer**



**Accessing the Adjustment Potentiometer:** Remove the two screws from the top of the printed circuit board (PCB) and gently slide the PCB from the housing. Use caution when removing the PCB. You will now be able to see the potentiometer through the housing. Make any necessary adjustment. Note: Electrical wiring of any liquid level control system should be performed in accordance with all applicable national, state, and local codes. When completed, gently return PCB into housing and replace the two screws.

## SAFETY PRECAUTIONS

### Step Four

**⚠ About this Manual:** PLEASE READ THE ENTIRE MANUAL PRIOR TO INSTALLING OR USING THIS PRODUCT. This manual includes information on the Switch Pro™ with Compact Relay Controller (Flow): AT17-\_6\_, AT16-\_6\_, AG17-\_6\_ and AG18-\_6\_. The units are identical except for the material of construction and the sensors technology.

**⚠ User's Responsibility for Safety:** Flowline manufactures a wide range of liquid sensors, controllers, and mounting systems. It is the user's responsibility to select components that are appropriate for the application, install them properly, perform tests of the installed system, and maintain all components. The failure to do so could result in property damage or serious injury.

**⚠ Proper Installation and Handling:** Use a proper sealant with all installations. Never overtighten the components. Always check for leaks prior to system start-up.

**⚠ Material Compatibility:**  
**Polypropylene (PP, a polyolefin):** Sensor, Junction Box.

**Ryton:** Sensor (AT1-\_16\_ and AG1-\_16\_ only).

**Polyvinylidene Fluoride (PVDF):** Sensor (AT1-\_36\_ and AG1-\_36\_ only).

Make sure that the application liquids are compatible with the materials that will be wetted. To determine the chemical compatibility between the components and its application liquids, refer to the Compass Corrosion Guide, available from Compass Publications (phone 858-589-9636).

**⚠ Temperature and Pressure:** Switch Pro™ is designed for use in application temperatures up to 50° C (140° F). The assembly is also designed for pressurized applications up to 150 psi (10 bar).

**⚠ Wiring and Electrical:** Electrical wiring of any liquid level control system should be performed in accordance with all applicable national, state, and local codes. Take care not to cut or break the outer insulation jacket of wiring that may be immersed while routing cables in the Switch Pro™ system. Such breaks of the liquid seal of the sensor system may lead to component failure.

**⚠ Flammable, Explosive and Hazardous Applications:** The AT17-\_6\_, AT18-\_6\_, AG17-\_6\_ and AG18-\_6\_ Switch Pro™ should not be used within classified hazardous environments.

**⚠ Make a Fail-Safe System:** Design a fail-safe system that accommodates the possibility of system or power failure. In critical applications, Flowline recommends the use of redundant back-up systems and alarms in addition to the primary system.

## ASSEMBLY OF SWITCH PRO™

### Step Five


**About Switch Pro™:** Flowline's Switch Pro™ with Compact Relay Controller is a single-point mounting system for installing one flow sensor within a pipe or fume.. The compact relay controller features a 120/240 VAC controller with a 250 VAC, 10A SPDT relay contact. Switch Pro™ typically mounts horizontally through a standard 3/4" NPT (3/4" G) tank adapter.

**Relay Controller:** The flow switch is pre-wired before shipment to the 3-pole terminal strip [Input 1 (+), (-) & (S)]. The technologies used to indicate flow is Thermal Dispersion. Both the liquid and gas configurations feature similar wiring/power configuration. The Compact Relay Controller provides a 1/2" Conduit connection and 6 poles for wire termination of power and relay contact. Use the AC, AC and GND terminals for providing power. Use the NC, NC and COM terminals for interfacing to the relay contact.




**Compact Relay Controller (inside shown)**

**Liquid (FT10-\_4\_5 or FT10-\_4\_5)**  
**Wire Configuration:**



**Gas (GT10-\_4\_5 or GT10-\_4\_5)**  
**Wire Configuration:**







## INSTALLATION

### Step Six

The AT1\_ series flow switch when installed must always be in contact with the liquid being measured. The AG1\_ series flow switch when installed must never be submersed in liquid. Both flow switches feature a 3/4" NPT threads which will allow it to be used with various types of fittings. Be sure to check the insertion depth of the flow switch in the fitting after it is installed. See the diagram below for the recommended insertion depth.



When using any type of fitting, the orientation as well as the insertion depth of the flow switch in the pipe is critical. See the diagram below for the recommended orientation depth.



### WARNING

The flow switch tips have a thin plastic wall which may be damaged if dropped or installed improperly.


The AT17 and AT18 flow switches are designed for use in liquid. For best results, avoid installing the AT1\_ where bubbles are present or where the tips of the switch may be out of the liquid.

The AG17 and a G18 flow switches are designed for use in gas applications. For best results, avoid installing the AG1\_ where it may be submersed in liquid.

Note: Always install the Viton gasket with all versions of the AT1\_-\_6\_4 and AG1\_-\_6\_4. The G threaded version will not seal unless the gasket is properly installed.

## GUIDE TO CONTROLS

### Step Seven




- 1. Power indicator:** This green LED lights when AC power is ON.
- 2. Relay indicator:** This red LED will light whenever the controller energizes the relay, in response to the proper condition at the sensor inputs and after the time delay.
- 3. AC Power terminals:** Connection of 120 VAC power to the controller. The setting may be changed to 240 VAC if desired. This requires changing internal jumpers; this is covered in the Installation section of the LC10/11 Series Manual. Polarity (neutral and hot) does not matter.
- 4. Relay terminals (NC, C, NO):** Connect the device you wish to control (pump, alarm etc.) to these terminals: supply to the COM terminal, and the device to the NO or NC terminal as required. The switched device should be a noninductive load of not more than 10 amps; for reactive loads the current must be derated or protection circuits used. When the red LED is ON and the relay is in the energized state, the NO terminal will be closed and the NC terminal will be open.
- 5. Invert switch:** This DIP switch reverses the logic of the relay control in response to the sensor(s): conditions that used to energize the relay will make it turn off and vice versa.
- 6. Time Delay:** After the input(s) change(s) state, this control sets a delay from 0.15 to 60 seconds before the relay will respond.
- 7. Input 1A indicator:** These amber LED will light immediately whenever the appropriate sensor attached to the terminals detects liquid, and will turn off when it is dry.
- 8. Input terminals:** Connect the wiring from the sensors to these terminals. Note the polarity: (+) is a 13.5 VDC, 27 mA power supply, and (-) is the return path from the sensor. If polarity is reversed, the sensors will not work.


## WIRING

### Step Eight


**VAC Power Input Wiring:** Observe the labeling on the controller. *Note: Polarity does not matter with the AC input terminal.*



**Relay Input Wiring:** The relay is a single pole, double throw type rated at 250 Volts AC, 10 Amps. The terminals Normally Open (NO) and Normally Closed (NC) will be used in different applications. Remember that the "normal" state is when the relay coil is de-energized and the Red relay LED is OFF (de-energized).




A typical application for the Switch Pro™ with Compact Relay Controller is to operate a pump or valve between the two set points (automatic fill or empty). In this application, a pump or valve can be wired to either the Normally Open (NO) or Normally Closed (NC) side of the relay.



### Strobe Alert Output

With the Strobe Alert wired NO, the strobe will flash when the Red LED is ON (Invert OFF). The strobe will flash when the Red LED is OFF when wired NC or by turning the Invert ON. If the strobe is wired NC and the Invert is ON, the strobe will flash when the Red LED is ON (same as NO wiring and Invert OFF).



## MAINTENANCE

### Step Nine

**General:** The Switch-Pro™ flow switch requires no periodic maintenance except to clean off any deposits or scaling from the sensor tip as necessary. It is the responsibility of the user to determine the appropriate maintenance schedule, based on the specific characteristics of the application liquids.

### Cleaning Procedure:

- 1. Power:** Make Sure that all power to the sensor, controller and/or power supply is completely disconnected.
- 2. Sensor Removal:** *Make sure that the flow is off and the pressure is down prior to removing the Switch-Pro™.* Carefully, remove the sensor from the installation. Replace the sensor with a 3/4" NPT plug to insure that liquid does not leak out during this procedure. **Do not re-install the Switch-Pro™ if the threads are damaged.**
- 3. Cleaning the Sensor:** Use a soft bristle brush and mild detergent, carefully wash the Switch-Pro™ flow switch. Do not use harsh abrasives such as steel wool or sandpaper, which might damage the surface sensor. Do not use incompatible solvents which may damage the sensor's PP/Ryton or PVDF plastic body.
- 4. Sensor Installation:** Follow the appropriate steps of installation as outlined in the installation section of this manual.

### Testing the Flow Switch:

Used to verify if the sensor is indicating a no-flow or flow condition. This test uses all four-wires (Red, Black, White and Green). With Red to Positive and Black to Negative, the Contacts (White and Green) will be Open in a Flow Condition and Closed in a No-Flow Condition. Also, the Red LED in the switch will be OFF for a Flow Condition and ON for a No-Flow Condition.

