

Technical Support

For complete product documentation, video training, and technical support, go to www.flowline.com.

For phone support, call 562-598-3015 from 8am to 5pm PST, Mon - Fri.
(Please make sure you have the Part and Serial number available.)

Flowline Inc. 10500 Humbolt St, Los Alamitos, CA 90720

FLOWLINE®

Warranty

Flowline warrants to the original purchaser of its products that such products will be free from defects in material and workmanship under normal use and service in accordance with instructions furnished by Flowline for a period, which is equal to the shorter of one year from the date of purchase of such products or two years from the date of manufacture of such products. Flowline's obligation under this warranty is solely and exclusively limited to the repair or replacement, at Flowline's option, of the products or components, which Flowline's examination determines to its satisfaction to be defective in material or workmanship within the warranty period. Flowline must be notified pursuant to the instructions below of any claim under this warranty within thirty (30) days of any claimed lack of conformity of the product. Any product repaired or replaced under this warranty will be warranted only for the remainder of the original warranty period.

Returns

Products cannot be returned to Flowline without Flowline's prior authorization. To return a product that is thought to be defective, go to www.flowline.com, and submit a customer return (MRA) request form and follow the instructions therein. All warranty and non-warranty product returns to Flowline must be shipped prepaid and insured. Flowline will not be responsible for any products lost or damaged in shipment.

Limitations

This warranty does not apply to products which: 1) are beyond the warranty period or are products for which the original purchaser does not follow the warranty procedures outlined above; 2) have been subjected to electrical, mechanical or chemical damage due to improper, accidental or negligent use; 3) have been modified or altered; 4) anyone other than service personnel authorized by Flowline have attempted to repair; 5) have been involved in accidents or natural disasters; or 6) are damaged during return shipment to Flowline. Flowline reserves the right to unilaterally waive this warranty and dispose of any product returned to Flowline where: 1) there is evidence of a potentially hazardous material present with the product; or 2) the product has remained unclaimed at Flowline for more than 30 days after Flowline has dutifully requested disposition. This warranty contains the sole express warranty made by Flowline in connection with its products. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. The remedies of repair or replacement as stated above are the exclusive remedies for the breach of this warranty. IN NO EVENT SHALL FLOWLINE BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND INCLUDING PERSONAL OR REAL PROPERTY OR FOR INJURY TO ANY PERSON. THIS WARRANTY CONSTITUTES THE FINAL, COMPLETE AND EXCLUSIVE STATEMENT OF WARRANTY TERMS AND NO PERSON IS AUTHORIZED TO MAKE ANY OTHER WARRANTIES OR REPRESENTATIONS ON BEHALF OF FLOWLINE. This warranty will be interpreted pursuant to the laws of the State of California. If any portion of this warranty is held to be invalid or unenforceable for any reason, such finding will not invalidate any other provision of this warranty.



Model: XP88/89

EchoSafe®

Quick Start



QS300600 Rev.A
©2010 Flowline, Inc.
All Rights Reserved
Made in USA

10500 Humbolt Street, Los Alamitos, CA 90720 USA
Tel: 562.598.3015 Fax: 562.431.8507 www.flowline.com

Welcome to the EchoSafe® Quick Start

The EchoSafe® Quick Start is meant to show some of the more common setup solutions to getting the EchoSafe® up and running quickly. If you run into an issue that is not addressed here or wish to install or set up with a non-standard configuration, please address the EchoSafe® Manual or refer to the Flowline website at www.flowline.com.

We Do Your Level Best

Thank you for purchasing Flowline's EchoSafe® explosion-proof, ultrasonic level transmitter. The sensor provides 4-20 mA analog output with integrated LCD and three push-button configuration. This Quick Start includes everything you'll need to get the sensor up and running. For complete information, please refer to EchoSafe® documentation located at www.flowline.com.

Components

Depending on the EchoSafe® model shipped to you, you should have the components shown below. Both components – the EchoSafe® and Viton® gasket – are required to configure and install the sensor



EchoSafe®
XP88, XP89



Viton® gasket
Part # 200129 (2")



Opening the Enclosure

The EchoSafe® is designed to be installed in hazardous areas and should never be opened while power is applied. Always disconnect the EchoSafe's power source prior to opening, programming, installing, or removing. Additionally, ensure that electrical wiring, fittings and mechanical connections conform to all applicable electrical codes.

Proper Installation & Handling

Only properly trained staff should install and/or repair this product. Never over tighten the transmitter within the fitting. Always check for leaks prior to system start-up.

Select Fail Safety Output

In the event the transmitter does not receive an echo, the Select Fail Safety Output setting can be set to 22mA, 21mA, 20mA, 4mA or HOLD last value to achieve the desired fail-safe condition. During fail-safe, the display will read lost.

- 1) Enter the configuration menu (as discussed previously),
- 2) Select **OUTPUT** from the menu,
- 3) Select **SAFE** from the menu,
- 4) Select an output option, such as **22mA**, **21mA**, **20mA**, **4mA**, or **HOLD**, and
- 5) Select **EXIT** twice to return to the top level of the Configuration menu.

Reverse 4-20 mA Signal

The transmitter allows you to switch the 4-20 mA value at the top and bottom of the application. By default, 4mA is configured as the bottom and 20mA is configured as the top. Follow these instructions to reverse this setting:

- 1) Enter the configuration menu (as discussed previously),
- 2) Select **OUTPUT** from the menu,
- 3) Select **Rev MA** from the menu,
- 4) Select **Rev** from the menu, and
- 5) Select **EXIT** twice to return to the top level of the Configuration menu.

Troubleshooting

If you face any issues not addressed in this quick start, please refer to the EchoSafe® Manual located on Flowline website at www.flowline.com.

Safety Concern


Where personal safety or significant property damage can occur due to a spill, the installation must have a redundant backup safety system installed.

Set Units

The sensor displays information in inches, feet, centimeters, meters, or percentages.

This can represent the amount of air or the amount of liquid in a tank. Air Display Mode shows the distance from the bottom of the sensor to the liquid surface. Liquid Display Mode shows the distance from the liquid surface to the bottom of the tank. Follow these instructions to set how units are displayed:

- 1) Enter the Configuration menu (as discussed previously),
- 2) Select **UNITS** from the menu,
- 3) Select the type of unit or the type of display you desire, and
- 4) Select **EXIT** to return to the Configuration menu.




Setting Units

Set Height and Fill Height

This setting customizes the reading for your installation. Follow these instructions to set the height and fill height for your tank:

- 1) Enter the configuration menu (as discussed previously),
- 2) Press SELECT when Tank appears,
- 3) Select **HEIGHT**. Use the UP and DOWN buttons to set the height of your tank. Then, hold down the SELECT button to save this setting,
- 4) Select **FILL-H** for the fill height. Use the UP and DOWN buttons to set the fill height of your tank. Then, hold down the SELECT button to save this setting, and
- 5) Select **EXIT** to return to the Configuration menu.



Setting Fill Height

Mounting the Transmitter

The transmitter should always be mounted perpendicular to the liquid surface using the provided Viton® mounting gasket. Insure that there are no restrictions or obstacles in the path of the ultrasonic signal. Further mounting information can be found on the Flowline website at www.flowline.com.


Mounting with a Tank Adapter: Select a tank adapter fitting, such as the LM52-2890.

Mounting with a Riser: As installations with tall, narrow risers can impede the acoustic signal. 2" diameter risers should be no taller than 4". Larger diameter risers should be no taller than 12".

Mounting with a Side Mount Bracket: Use Flowline's LM50-1001 side mount bracket.



Riser Mounting



Mounting with a Stand Pipe: A standpipe may be used to dampen turbulence, separate surface foam from the point of measurement or increase performance in heavy vapor. Select a 3" or 4" pipe and attach the sensor with a coupling and reducer bushing. The pipe length should run the measurement span and the bottom of the pipe should remain submerged at all times to prevent foam from entering the pipe. Cut the bottom end of the pipe at 45° and drill a 1/4" pressure equalization hole high in the dead band. The pumps should not drive liquid past the open end of the standpipe which causes the liquid in the pipe to oscillate.



Stand Pipe Mounting

IMPORTANT MOUNTING GUIDELINES:


- 1) Never mount the transmitter at an angle.
- 2) Liquid should never enter the dead band.
- 3) Mount at least 3" from the side wall.
- 4) Never mount in a vacuum.
- 5) Do not obstruct the transmitter's beam width.

Wiring the Transmitter

The below wiring diagram can be used to wire the Transmitter.

Some notes on safety:

- Wiring should always be completed by a licensed electrician.
- Supply voltage should never exceed 28 VDC.
- The sensor must be chemically compatible with the application.
- Design a fail-safe system for possible sensor and/or power failure.
- When installed in hazardous locations, follow all established safety precautions.
- Where personal safety or significant property damage can occur due to a spill, the installation must have a redundant backup safety system installed.




Configuring the Transmitter

The transmitter features a non-volatile memory and can be configured prior to installation. Your configuration will not be lost when the transmitter is powered down.

Before configuring, be sure to have the following information:

Height. This is the distance from the transducer face to the bottom of the tank.

Fill Height (Fill-H). This is the distance from the highest level of liquid to the bottom of the tank



Height and Fill Height

Entering Configuration Menu

The sensor is configured with the three button's on the transmitter 's face (**UP**, **DOWN** and **SELECT**) and the sensor 's LCD. To access the transmitter's configuration menu, simply hold down the SELECT button for five seconds or until the menu is displayed. When the SELECT button is released, the display menu will begin to scroll through the uppermost level of the configuration menu.

When the menu scrolls to an item you wish to configure, simply press the SELECT button again when that item appears. Once you've made your configuration changes, press SELECT again to scroll through the options and once more while RUN appears in the display. This will return the sensor to its operational mode.



The Transmitter's Interface



Handling Static-Sensitive Surfaces/Devices

Follow the guidelines below to reduce any possible electrostatic charge build-up when handling the EchoSafe®.

1. Always touch a reliable ground source before handling the EchoSafe®. This should be repeated while handling the EchoSafe® and more frequently after sitting down from a standing position, sliding across the seat or walking a distance.
2. Avoid touching the EchoSafe's electrical terminals except when making connections.